



dc15xx

CONTROL

AB610A5020



Instruction Manual with list of parameters

- Putting into Service
- Settings
- Functional Description
- Connection Diagrams
- Timing Diagrams

No. 402440 English

Note
For initial operation after software updating or maintenance procedures, make sure to set parameter 467 for the specific motor to be used.
DC1500, F-467 = 1 / DC1550, F-467 = 2

Important Notes

The particulars used in various figures and tables, such as type, program number, speed, etc., serve as examples. They may differ from those in your display.

For current versions of the Instructions for Use and Lists of Parameters, necessary for operating EFKA drives in accordance with regulations, please refer to the EFKA web site www.efka.net, page "**Downloads**".

On our web site you will also find the following supplementary instructions for this control:

- ✕ General instructions for use and programming
- ✕ Use with USB Memory Stick

CONTENTS	Page
1 Range of Applications	4
1.1 Use in Accordance with Regulations	4
2 Scope of Supply	4
2.1 Special Accessories	5
3 Putting into Service	6
4 Setting and Putting into Service with the Aid of the Fast Installation Routine (SIR)	6
5 Setting the Basic Functions	7
5.1 Direction of Motor Rotation	7
5.2 Use of a HSM001 Hall Sensor Module or IPG... Pulse Encoder	7
5.3 Transmission Ratio	8
5.4 Positioning Speed	8
5.5 Maximum Speed Compatible with the Sewing Machine	8
5.6 Maximum Speed	8
5.7 Positions	9
5.7.1 Setting the Reference Position (Parameter 270 = 0 or 6)	9
5.7.2 Setting the Positions (Parameter 270 = 0 or 6)	9
5.8 Display of the Signal and Stop Positions	10
5.9 Positioning Shift	10
5.10 Braking Characteristics	10
5.11 Braking Power at Standstill	10
5.12 Starting Characteristics	11
5.13 Operating Hours Counter	11
5.13.1 Set and Reset Operating Hours Counter	12
5.13.2 Total Operating Hours Display	12
6 Functions	12
6.1 First Stitch after Power On	12
6.2 Softstart	12
6.2.1 Softstart speed	12
6.2.2 Softstart stitches	12
6.3 Special pedal function Single stitch / Full stitch	13
6.4 Actuator	13
6.4.1 Analog actuator	13
7 Operating Elements and Socket Connectors	14
7.1 Positions of the Front Side	14
7.2 Positions of the Rear Side	14
7.3 Connection Diagrams	15
8 List of Parameters	16
8.1 Operator Level	16
8.2 Technician Level	16
8.3 Supplier Level	18
9 Error Displays	21

1 Range of Applications

The drive is suitable for lockstitch, chainstitch and overlock machines of various manufacturers.

1.1 Use in Accordance with Regulations

The drive is not an independently operating machine, but is designed to be incorporated into other machinery by specially trained personnel.

It must not be put into service until the machinery into which it is to be incorporated has been declared in conformity with the provisions of the EC Directive (Appendix II, paragraph B of the Directive 89/392/EEC and supplement 91/368/EEC).

The drive has been developed and manufactured in accordance with the relevant EC standards:

IEC/EN 60204-31 Electrical equipment of industrial machines:
Particular requirements for industrial sewing machines, sewing units and sewing systems.

Operate the drive only in dry areas.



ATTENTION

When selecting the installation site and the layout of the connecting cable, the Safety Instructions must be followed with no exceptions.
Particular attention should be paid to maintaining the proper distance from moving parts!

2 Scope of Supply

Standard Scope of Supply		
1	Direct current motor	DC1500 optional DC1550
1	Electronic control/Power supply unit	AB610A5020/N215
1	Actuator	EB401
1	Set of accessories (standard)	B156
	consisting of:	Plastic bag for B156 + documentation
and		
1	Set of accessories	Z68
	consisting of:	Pitman rod, potential equalization cord
Option 1		
1	Set of standard accessories	B159
	consisting of:	Undertable mounting kit, Plastic bag for B159 + documentation
and		
1	Set of accessories	Z68
	consisting of:	Pitman rod, potential equalization cord

NOTE

If there is no metallical contact between drive (motor) and machine head, the potential equalization cord supplied with the unit is to be wired from the machine head to the terminal provided on the control box!

2.1 Special Accessories

The special accessories available ex works allow the augmentation and enhancement of functions, operating, connecting, and mounting options.

Since the range of available components is continually expanded, we kindly ask you to contact us in case of need.

Designation	Material No.
Hall sensor module HSM001	6100032
Pulse encoder IPG001	6100033
Extension cable approx. 1000 mm long for commutation transmitter DC15..	1113151
Extension cable approx. 1000 mm long for DC15.. line	1113150
Potential equalization cord 700 mm long, LIY 2.5 mm ² , gray, with spades on both sides	1100313
Fitting piece for position transmitter	0300019
Undertable mounting kit for DC15..	1113235
Undertable mounting kit (reinforced) for DC15..	1113427
9-contact SubminD male connector	0504135
9-contact SubminD female connector	0504136
Half-shell housing for 9-contact SubminD	0101471

3 Putting into Service

NOTE

When using of the drive to compensate for a coupling motor without positioning, configuration of the parameters is not required when GREP. The associated parameters have no effects.

Before putting the control into service, the following must be ensured, checked and/or adjusted:

- Auswahl des Motortyps DC1500 oder DC1550 (Parameter 467)
- The correct installation of the drive, position transmitter and accompanying devices, if necessary
- If necessary, the correct adjustment of the direction of motor rotation using parameter 161
- The setting of the transmission ratio between motor shaft and machine shaft using parameter 272
- The setting of the type of position sensor using parameter 270
- If necessary, the setting of the positions using parameter 171 (possible with all settings of parameter 270)
- The correct positioning speed using parameter 110
- The correct maximum speed compatible with the sewing machine using parameter 111
- The setting of the remaining relevant parameters
- Begin sewing in order to save the set values

4 Setting and Putting into Service with the Aid of the Fast Installation Routine (SIR)

Functions	Parameter
Call-up of the Fast Installation Routine SIR	(Sir) 500

The Fast Installation Routine (SIR) passes through all parameters necessary for programming the functional sequence and the positions.

Input parameter 500



Parameter for selection of motor
(1=DC1500, 2=DC1550)



Parameter for direction of motor rotation



Parameter for transmission ratio
Important! The transmission ratio should be determined and indicated as precisely as possible.




Parameter for type of position sensor



Parameter for position 1



Parameter for position 2



The values can be varied by pressing keys +/-.

With SIR you can do the most important settings for initial operation with menu prompting. For safety reasons, the menu must be executed point by point. This ensures correct setting of all important parameters. The setting of other parameters is not affected.

5 Setting the Basic Functions

5.1 Direction of Motor Rotation

Function		Parameter
Direction of motor rotation	(drE)	161

161 = 0 Clockwise motor rotation (look at the motor shaft)

161 = 1 Counterclockwise motor rotation




ATTENTION

If the motor is mounted differently, e. g. at a different angle or with gear, make sure that the value set using parameter 161 corresponds to the direction of rotation.


5.2 Use of a HSM001 Hall Sensor Module or IPG... Pulse Encoder

Representation and installation of a HSM001 Hall sensor module or IPG... pulse encoder



KL2521


Operation with HSM001 Hall sensor module



KL2523

- ←
- Get machine to the needle-up position.
- Position bore for magnet such that the magnet is located approx. 15° after the sensor in the sense of rotation.
- Get machine to the needle-up position.
- Turn disk in the pulse encoder such that the leading edge will be located approx. 15° after the sensor on the board in the sense of rotation.

Operation with IPG... pulse encoder



KL2524

5.3 Transmission Ratio

NOTE

The transmission ratio must always be input, because only motors with integrated incremental transmitter will be used. **The transmission ratio should be determined and set as precisely as possible!**

The transmission ratio between motor shaft and shaft of the sewing machine head must be input, so that the set speeds of parameters 110...117 correspond to the sewing speeds.

Function	Parameter
Transmission ratio between motor shaft and machine shaft (trr)	272

The transmission ratio can be selected within a range of 020...9999 using parameter 272.

Example: With a motor pulley diameter of 40mm and a sewing machine head pulley diameter of 80mm the value 500 can be calculated using the formula below.
If the value 2000 has been selected in parameter 272, it follows that the motor pulley is double the size of the sewing machine head pulley.

$$\text{Value of parameter 272} = \frac{\text{Motor pulley diameter}}{\text{Machine pulley diameter}} \times 1000$$

5.4 Positioning Speed

Function	Parameter
Positioning speed (n1)	110

The positioning speed can be set using parameter 110 on the control within a range of 70...390 RPM.

5.5 Maximum Speed Compatible with the Sewing Machine

The maximum speed of the machine is determined by the selected pulley and by the following settings:

- Set the maximum speed using parameter 111 (n2)
- Set the maximum speed limitation to the specific level according to the application as described in chapter "Direct Input of Maximum Speed Limitation (DED)".

5.6 Maximum Speed

Function	Parameter
Maximum speed (n2)	111

NOTE

See instruction manual of the sewing machine manufacturer for the maximum speed of the sewing machine.

NOTE

Select the pulley such that the motor runs at approx. 4000 RPM with max. number of stitches.

5.7 Positions

Function		Parameter
Modus of a position sensor	(PGm)	270
Setting the needle positions	(PGr)	171
Transmission ratio between motor shaft and machine shaft	(trr)	272

A sensor can be used as a position sensor, e.g. a light barrier or proximity switch with either NC or NO functionality.

It is connected to socket B18/7.

Parameter 270 is used to select the mode to be selected depending on the type and mounting of the sensor used (see section Parameter List under parameter 270 for a description and flow chart).

After configuration of parameter 270 to "1, 2, 3, or 4", parameter 171 must be used to set the angle for positions 1 and/or 2, incoming and outgoing.

Alternatively, the positions can be configured using the fast-installation routine.

The transmission ratio must already have been input using parameter 272.

5.7.1 Setting the Reference Position (Parameter 270 = 0 or 6)

The angular positions necessary on the machine e.g. "needle down position" or "thread lever up position" are stored in the control. A reference position is needed in order to establish a relationship between position transmitter information and actual mechanical position.

The reference position must be set:

- for initial operation
- after replacing the motor

Setting the reference position:

- Input code number and select parameter **170**.
- Press the **E** key → Display **Sr1**
- Press key **>>** → Display **P o** (character o rotating)
- Turn handwheel until rotating character **o** goes off on the display. → Display **P**
- By turning the handwheel, set the needle to the bottom dead center, or the needle point to the height of the needle plate in the direction of rotation of the motor shaft, while needle is moving downward. → Set machine reference point
- Press the **P** key once → Actual parameter number is displayed
- Press the **P** key twice → Exit programming at the technician level

5.7.2 Setting the Positions (Parameter 270 = 0 or 6)

Do these settings whenever the encoder incorporated in the motor is used (parameter 270 = 0), or a position transmitter mounted on the machine head (e.g. IPG pulse encoder or HSM Hall sensor) (parameter 270 = 6), whose preset values must be adapted.

- Nach Eingabe der Code-Nummer Parameter **171** wählen!
- Press the **E** key → **[o]** is displayed
- Press key **>>** → **P1E** is displayed; set "position 1 On" on the handwheel
- Press the **E** key → **P2E** is displayed; set "position 2 On" on the handwheel
- Press the **E** key → **P1A** is displayed; set "position 1 Off" on the handwheel
- Press the **E** key → **P2A** is displayed; set "position 2 Off" on the handwheel
- Press the **P** key twice → Exit programming at the technician level

5.8 Display of the Signal and Stop Positions


Function		Parameter
Display of positions 1 and 2	(Sr3)	172

The position settings can easily be checked by means of parameter 172.

- Select parameter 172
- The control panel display shows "Sr3"
- Turn handwheel according to the direction of motor rotation

Control display

- Segment **5** turns on corresponds to position 1
- Segment **5** turns off corresponds to position 1A
- Segment **6** turns on corresponds to position 2
- Segment **6** turns off corresponds to position 2A



5.9 Positioning Shift

Function		Parameter
Positioning shift	(PSv)	269

Determine by means of parameter 269 whether the drive is to stop exactly on the position (parameter 269 = 0) or some increments after the position.

5.10 Braking Characteristics

Function		Parameter
Braking effect when varying the preset value ≤ 4 stages	(br1)	207
Braking effect when varying the preset value ≥ 5 stages	(br2)	208

- Parameter 207 regulates the braking effect between speed stages
- Parameter 208 influences the braking effect for the stop

The following applies to all setting values: the higher the value, the stronger the braking reaction!

5.11 Braking Power at Standstill

Function		Parameter
Braking power at standstill	(brt)	153

This function prevents unintentional "wandering" of the needle at standstill. The effect can be checked by turning the handwheel.

- The braking power is effective at standstill
 - at stop in the seam
 - after the seam end
- The effect can be set
- The higher the set value, the stronger the braking power

5.12 Starting Characteristics

Function		Parameter
Starting edge	(ALF)	220

The drive acceleration dynamics can be adapted to the sewing machine characteristic (light/heavy).

- High setting value = high acceleration

With a high starting edge setting and, in addition, possibly high braking parameter values on a light machine, the characteristic may appear coarse. In this case, one should try to optimize the settings.

5.13 Operating Hours Counter

Function		Parameter
Acoustic signal	(AkS)	127
Service routine for total operating hours	(Sr6)	176
Service routine for operating hours before service	(Sr7)	177
Input of operating hours before service	(Sr)	217

The integrated operating hours counter records the time of motor operation. Downtimes are not recorded. Time recording accuracy is 1ms. There are two ways of operating hours counting.

1. Basic Operating Hours Counting:

217 = 0 Operational mode: Operating hours counting

2. Service Hours Monitoring:

- 217 = >0** Operational mode: Number of operating hours before the next service.
 Input of operating hours before the next service.
 This value is compared to the operating hours counter.
 The hours are programmed in steps of 10, i. e. the lowest display of 001 corresponds to 10 hours (e. g. 055 = 550 hours).
 When the set number of operating hours are reached, the message "C1" will show on the display after each seam end.
- 176** In this service routine, the total operating hours can be read out according to the procedure example described below for parameter 177.
- 177** Display of operating hours since the **last** service.

Display example of operating hours or hours since the last service and operating hours counter reset.

Control display:

- Select parameter 177.
- Press the **E** key → **Sr7**
- Press the **>>** key → **h t** (hours /thousands letter symbol)
- Press the **E** key → **000** (hours /thousands display)
- Press the **E** key → **h h** (hours / hundreds letter symbol)
- Press the **E** key → **000** (hours / hundreds display)
- Press the **E** key → **Min** (minutes letter symbol)
- Press the **E** key → **00** (minutes display)
- Press the **E** key → **SEc** (seconds letter symbol)
- Press the **E** key → **00** (seconds display)
- Press the **E** key → **MS** (milliseconds letter symbol)
- Press the **E** key → **000** (milliseconds display)
- Press the **E** key → **rES** see chapter "Set and Reset Operating Hours Counter"
- Press the **E** key → The process will be repeated from the hours display.
- Press the **P** key twice → z. B. **400** (sewing process can be started)

5.13.1 Set and Reset Operating Hours Counter

The number of hours has been reached (service necessary):

- Press the >> key once → The operating hours counter is set to "0" and restarted.

The number of hours has not yet been reached:

- Press the >> key 3 times → The operating hours counter is set to "0" and restarted.

A value in parameter 177 has been changed:

- After displaying **rES** ..., when the **E** key is pressed again, **SEt** will then be displayed.
- If the changed value is to be saved, press the >> key 3 times.

5.13.2 Total Operating Hours Display

In this service routine enabled using parameter 176, the total number of operating hours is displayed.

The sequence of displayed values is as with parameter 177.

The values can only be displayed, not varied. Therefore, letter symbols "rES" for "reset" and "SEt" for "set" will not appear.

6 Functions

6.1 First Stitch after Power On

Function	Parameter
1 stitch at positioning speed after power On	(Sn1) 231

If parameter **231** is on, the first stitch after power on will be performed at positioning speed for the protection of the sewing machine. This is independent of the pedal position and the softstart function.

6.2 Softstart

Function	Parameter
Softstart On/Off	(SSt) 134

Functions:

- after power on
- at the beginning of a new seam
- speed pedal controlled and limited to (n6)
- lower speed of a parallel function prevailing (e. g. stitch counting)
- stitch counting synchronized to position 1
- suspension with pedal in position 0 (neutral)
- interruption by full heelback (position -2)

6.2.1 Softstart speed

Function	Parameter
Softstart speed	(n6) 115

6.2.2 Softstart stitches

Function	Parameter
Number of softstart stitches	(SSc) 100

6.3 Special pedal function Single stitch / Full stitch

Function		Parameters
Special pedal function Single stitch / Full stitch	(EzP)	041
Pedal travel forwards for detection of the special pedal function	(GrP)	042
Time for detection of the special pedal function	(dPd)	051
Speed for single stitch / full stitch	(n9)	122

With the single stitch / full stitch, it is possible to enable the execution of a stitch though pedal forwards actuation. For this it is necessary to move the pedal forward only far enough so that the percentage portion (e.g., 40%) of the maximum possible pedal travel (100%) set by the parameter **042**, is not exceeded.

The execution is done as single stitch (parameter **041 = 1**) or full stitch (parameter **041 = 2**)

If the travel set with parameter **042** is exceeded within the time set with parameter **051**, the drive runs with the speed specified by the respective pedal setting, even when under the threshold.

First after pedal 0-position can the special pedal function be actuated again.

The single/full stitch is executed in the speed set with parameter **122**. To ensure that only a single stitch is executed, the setting 300 rpm must not be exceeded.

041 = 0 Special pedal function Off

041 = 1 Single stitch:

The performs one rotation from position 1 to position 1. If it is standing in position 2, it runs to position 1 the first time and then each time from position 1 to position 1.

041 = 2 Full stitch:

The drive executes a complete rotation corresponding to its starting position.

6.4 Actuator

6.4.1 Analog actuator

Function		Parameter
Characteristic of the "analog pedal" EB401	(APd)	026

The characteristic of the "analog pedal" can be set using parameter **026**:

026 = 0 Analog function off

026 = 1 12-level selected, like prior pedal function of the digital actuator.

026 = 2 continuously variable


026 = 3 24-level

026 = 4 60-level (progressive)

7 Operating Elements and Socket Connectors


7.1 Positions of the Front Side

A	Power switch
B	Mains pilot lamp
C	Control panel (onboard module) + Display (4 digit 7 segment display)
Key	
P	Call or exit programming mode
E	Softstart On/Off
+	Enter key for modifications in the programming mode
+	In the programming mode - increase of the value indicated
>>	Basic position 1 or 2
>>	Shift key in the programming mode
-	In the programming mode – decrease of the value indicated
The upper vertical segments of the 4 digit 7 segment display indicate the switching states of foot lifting and basic position.	
1	Softstart On/Off
5	Basic position “needle position 1”
6	Basic position “needle position 2”
Connector	
B20	USB Memory Stick




7.2 Positions of the Rear Side

Steckverbinder	
B2	Commutation transmitter
B18	- Hall sensor module HSM001 - Pulse encoder IPG001
B41	Motor power supply
B80	Actuator



7.3 Connection Diagrams


Connection of a HSM001 Hall sensor module or an IPG001 pulse encoder



BI2003

POS2 OUT	Output for position 2	TXD/RXD	Serial transmission lines
POS IN	Input for positions (e. g. connection of a sensor)	HSM001	Hall sensor module
G1/G2 OUT	Output of generator impulses	IPG...	Pulse encoder

Connection of an analog actuator EB401



BI2004

1) Nominal voltage +5 V, I_{max} 100 mA

2) Nominal voltage +5 V, I_{max} 20 mA

3) Logic level output +5 V, I_{max} 5 mA

*) Front view of the control (component side) / rear view of the outgoing connecting cable

8 List of Parameters

8.1 Operator Level

Operator Level

Parameter	Designation	Unit	max	min	Preset	Ind.
026 APd	Characteristic of the "analog pedal" EB401 0 = Analog function off 1 = 12-level, like previous pedal function 2 = continuously variable 3 = 24-level 4 = 60-level (progressive)		4	0	4	
041 EZP	Special pedal function Single stitch / Full stitch 0 = Function off 1 = Single stitch 2 = Full stitch		2	0	0	C
042 GrP	Pedal travel forwards for detection of the special pedal function	%	100	0	40	C
051 dPd	Time for detection of the special pedal function	ms	2550	0	100	C

8.2 Technician Level

Code no. 1907

Parameter	Designation	Unit	max	min	Preset	Ind.
100 SSc	Number of softstart stitches	stitches	254	0	2	
110 n1	Positioning speed	RPM	390	70	200	
111 n2	Upper limit setting range of the maximum speed	RPM	9900	n2_	5000	
121 n2	Lower limit setting range of the maximum speed	RPM	n2_	200	400	
134 SSt	Softstart On/Off		1	0	0	
161 drE	Direction of motor rotation 0 = Clockwise rotation 1 = Counterclockwise rotation		1	0	0	
170 Sr1	Setting the reference position: - Press the E key - Press the >> key. - Turn handwheel until symbol on display goes off. Then set the handwheel to the reference position. - Press the P key twice					
171 Sr2	Setting the needle positions: 1E = Start position 1 2E = Start position 2 1A = End position 1 2A = End position 2	degrees	359	0	26 319 200 355	
172 Sr3	Display on the control: Pos. 1 bis 1A (LED-segment 5 lights up) Pos. 2 bis 2A (LED-segment 6 lights up)					
176 Sr6	Service routine for total operating hours display. The process is as with display example of parameter 177.					

Technician Level

Code no. 1907

Parameter	Designation	Unit	max	min	Preset	Ind.
177 Sr7	Service routine for display of hours since the last service. Display example for the operator control panel: Press the E key → Display Sr7= Press the >> key → Display h t Press the E key → Display 0000 Press the >> key → Display h h Press the E key → Display 0000 Press the E key → Display Min Press the E key → Display 00 Press the E key → Display SEc Press the E key → Display 00 Press the E key → Display MS Press the E key → Display 000 Press the E key → Display rES Press the E key again to restart routine, or press the P key twice to return to operational status					
179 Sr5	Display of control program number with index and more identification numbers. The data is displayed in sequence by keystroke. Display example for the operator control panel: Press the E key → Display Sr5= Press the >> key → Display e.g. 5020 (prog. no) Press the E key → Display e.g. A (Index) Press the E key → Display e.g. 06 (Year) Press the E key → Display e.g. 10 (Month) Press the E key → Display e.g. 24 (Day) Press the E key → Display e.g. 16 (Hour) Press the E key → Display e.g. -- Press the E key → Display e.g. ---- Press the E key again to restart routine, or press the P key twice to return to operational status					

8.3 Supplier Level

Code no. 3112


Parameter	Designation	Unit	max	min	Preset	Ind.
207 br1	Delay from end of thread wiper until sewing foot lifting On		55	1	15	
208 br2	Braking effect when varying the preset value ≤ 4 stages (indicated values only with transmission ratio 1:1)		55	1	20	
217 Sr	Number of operating hours before service in steps of 10 (operating hours recording enabled if set at "0").	hours	99900 ***)	00000	00000	
219 br3	Braking power at stop of the drive			1	4	
220 ALF	Accelerating power of the drive (indicated values only with transmission ratio 1:1)			1	35	
221 dGn	Speed gate 1	RPM	990	50	100	
222 tGn	Speed gate damping period	ms	990	0	20	
231 Sn1	Execution of the first stitch after Power On at positioning speed		1	0	0	

***) The 4-digit value displayed must be multiplied by 10.

Supplier Level

Code no. 3112

Parameter	Designation	Unit	max	min	Preset	Ind.
270 PGM	Modus of a position sensor with normally open function (N.O.)		6	0	0	
	0 = The positions are generated using the transmitter incorporated in the motor and can be set using parameter 171 *). 1 = Setting the sensor to position 2. Set position 1 using parameter 171 *), starting from trailing edge position 2. 2 = Setting the sensor to position 2. Set position 1 using parameter 171 *), starting from leading edge position 2. 3 = Setting the sensor to position 1. Set position 2 using parameter 171 *), starting from trailing edge position 1. 4 = Setting the sensor to position 1. Set position 2 using parameter 171 *), starting from leading edge position 1. 5 = No position sensor available. The drive stops unpositioned. 6 = The positions are determined by preset values. The reference position must be correctly set for this purpose. In machines with position sensors incorporated in the handwheel the reference position is determined by mechanical adjustment. In all other cases the reference position must be set (see chapter "Setting the Reference Position") in order for the angles preset for positions 1 and 2 to be correct. If necessary, the preset values can be adapted as described in chapters "Setting the Positions".					




The angles between positions 1 and 2, incoming and outgoing, can be configured using Parameter 171.

*) Alternatively, the positions can be configured using the fast-installation routine.

Supplier Level

Code no. 3112

Parameter	Designation	Unit	max	min	Preset	Ind.
270 PGm	Modus of a position sensor with normally closed function (N.C.) 0 = The positions are generated using the transmitter incorporated in the motor and can be set using parameter 171 *). 1 = Setting the sensor to position 2. Set position 1 using parameter 171 *), starting from trailing edge position 2. 2 = Setting the sensor to position 2. Set position 1 using parameter 171 *), starting from leading edge position 2. 3 = Setting the sensor to position 1. Set position 2 using parameter 171 *), starting from trailing edge position 1. 4 = Setting the sensor to position 1. Set position 2 using parameter 171 *), starting from leading edge position 1. 5 = No position sensor available. The drive stops unpositioned. 6 = The positions are determined by preset values. The reference position must be correctly set for this purpose. In machines with position sensors incorporated in the handwheel the reference position is determined by mechanical adjustment. In all other cases the reference position must be set (see chapter "Setting the Reference Position") in order for the angles preset for positions 1 and 2 to be correct. If necessary, the preset values can be adapted as described in chapters "Setting the Positions".		6	0	0	



The angles between positions 1 and 2, incoming and outgoing, can be configured using Parameter 171.

*) Alternatively, the positions can be configured using the fast-installation routine.

Parameter	Designation	Unit	max	min	Preset	Ind.
272 trr	Transmission ratio between motor shaft and machine shaft (calculation formula see instruction manual!) The transmission ratio should be determined and indicated as precisely as possible!		9999	150	1000	

Supplier Level

Code no. 3112

Parameter	Designation	Unit	max	min	Preset	Ind.
401 EEP	Immediate storage of all changed data - Input code number 3112 after power On - Press the E key - Input parameter 401 - Press the E key - Set display from 0 to 1 - Press the E or P key - All data are stored		1	0	0	
467 MOT	Selection of motor 1 = DC1500 2 = DC1550		2	1	1	
500 Sir	Recall of Fast Installation Routine (SIR) (see chapter "Fast Installation Routine (SIR)")					
510	Transfer parameter settings from control to Memory Stick					
511	Transfer parameter settings from Memory Stick to control					
512	Compare control and Memory Stick parameter settings					
513	Delete parameter setting file from Memory Stick					
526	Transfer control software from control to Memory Stick					
527	Transfer control software from Memory Stick to control					
528	Compare control and Memory Stick control software					
529	Delete control software file from Memory Stick					

9 Error Displays

On the control	Signification
General Information	
A1	Pedal not in neutral position when turning the machine on
A3	Reference position is not set
A11	The maximum speed configured cannot be reached at this transmission ratio
A500	Max. number of files (99) on Memory Stick exceeded
A501	File not found on Memory Stick
A503	Data on Memory Stick and in the control is not equal
C1	Operating hours counter has reached or exceeded the service time
C2	Fatal exception error
C3	Program error
Programming Functions and Values (Parameters)	
Springt zurück auf 0000 bzw. auf letzte Parameter- Nummer	Wrong code or parameter number input
Serious Condition	
E1	The external pulse encoder e.g. IPG... is defective or not connected.
E2	Line voltage too low, or time between power Off and power On too short
E3	Machine blocked or does not reach the desired speed. Wrong motor selected (param. 467)
E4	Control disturbed by deficient grounding or loose contact
E8	Too much data for the EEPROM or flash memory
E9	EEPROM or flash memory defective.
E14	Power voltage too high: The power voltage is greater than 290V eff. (The DC motor cannot be started; if running, the motor is stopped without positioning. The motor is passively braked (runs down)!
E15	Internal communications error with intermediate circuit
E16	Power voltage too low: The power feed voltage was less than 120V eff. (The DC motor cannot be started, and the 24V is turned off.)

E17	Charging PTC too warm. The intermediate circuit could not be charged to the voltage needed. Possible cause: Switching the controller on/off to many times within a short time. Correction: Turn off controller and allow it to cool. (The duration of the cooling off phase depends on the ambient conditions and can take several minutes).
E18	Intermediate circuit voltage greater than 450 V, braking resistance possibly failed
E19	No motor connected, inverter defective, motor phase failed
E20	Motor speed too high
Programming and Data Transfer	
F1	Parameter unavailable; wrong code number
F7	RS232 timeout
F8	RS232, error in data transfer, NAK received
Hardware Disturbance	
H1	Commutation transmitter cord or frequency converter disturbed
H2	Processor disturbed

For your notes:



FRANKL & KIRCHNER GMBH & CO KG
SCHEFFELSTRASSE 73 – 68723 SCHWETZINGEN
TEL.: +49-6202-2020 – FAX: +49-6202-202115
E-Mail: info@efka.net – www.efka.net



OF AMERICA INC.
3715 NORTHCREST ROAD – SUITE 10 – ATLANTA – GEORGIA 30340
PHONE: +1-770-457 7006 – FAX: +1-770-458 3899 – email: efkaus@bellsouth.net



ELECTRONIC MOTORS SINGAPORE PTE. LTD.
67, AYER RAJAH CRESCENT 05-03 – SINGAPORE 139950
PHONE: +65-67772459 – FAX: +65-67771048 – email: efkaems@efka.net