


DB1-B760




Please clarify Ref. No. and
Parts No. as well as parts name
When you place an order.

1 1020006

INDEX

Parts No.	Ref. No.	Remark	Parts No.	Ref. No.	Remark	Parts No.	Ref. No.	Remark	Parts No.	Ref. No.	Remark
100008-0-03	A-5		100265-0-14	B-11		100338-0-01	C-63		102630-0-01	B-23	
100013-0-02	C-10		100266-0-01	A-43		100339-0-01	C-57		102632-0-01	B-13	
100013-0-03	B-36		100268-0-01	A-39		100343-0-01	B-64		102921-0-02	C-24	
///	C-12		100269-0-01	A-40		100351-0-01	B-71		103013-0-01	C-4	
///	C-22		100271-0-01	B-16		100356-0-01	B-56		103555-0-00	B-41	
100016-0-01	B-15		100279-0-01	C-1		///	B-70		103557-0-01	B-55	
100016-0-03	B-26		100287-0-04	A-17		100367-0-01	B-77		103558-0-00	B-53	
///	B-31		///	C-6		100368-0-02	B-76		103738-0-01	B-45	
///	B-44		100288-0-01	C-11		100369-0-01	B-79		103796-0-01	B-46	
///	B-54		100290-0-01	C-16		100385-0-01	A-11		103797-0-01	B-62	
///	B-58		100291-0-01	C-9		100386-0-01	A-10		103950-0-02	A-29	
100032-0-01	A-42		100293-0-01	C-20		100388-0-04	A-27		103980-0-03	A-25	
100035-0-01	A-41		100294-0-01	C-15		100389-0-01	A-26		104274-0-00	B-34	
100036-0-03	C-64		100295-0-01	C-23		100390-0-01	A-16, B-17		104376-0-00	B-14	
100062-0-04	B-40		100297-0-01	C-21		100391-0-01	A-16		104464-0-00	B-18	
100075-0-03	C-51		100298-0-01	C-26		100392-0-01	A-21		104478-0-01	B-43	
///	C-61		100299-0-01	C-25		100393-0-01	A-19		104680-0-01	B-83	
100078-0-03	C-60		100300-0-01	C-28		///	A-22		///	B-85	
100080-0-03	C-13		100304-0-01	C-31		///	B-9		///	C-40	
///	C-56		100305-0-01	C-33		100395-0-01	A-18		106121-0-01	B-12~16	
100086-0-03	C-54		100308-0-03	C-32		100397-0-01	A-31		///	20, 21, 22	
100119-0-03	A-9		100307-0-00	B-37		100398-0-01	A-34		106424-0-04	B-87	
100134-0-01	A-36		100309-0-01	B-86		100399-0-01	A-33		106440-0-00	B-89	
100136-0-01	A-38		100310-0-01	B-82		100400-0-00	A-32		106442-0-01	B-88	
100137-0-01	B-25		///	B-84		100401-0-01	A-37		107428-0-01	B-80	
100235-0-00	A-1		///	C-38		100402-0-02	A-30		108520-0-01	A-14	
///	A-2		100311-0-00	C-39		100404-0-00	C-17		109208-0-01	B-5	
///	A-3		100312-0-01	C-41		100405-0-01	C-19		109801-0-01	C-8	
///	A-8		100313-0-01	C-35		100539-0-02	B-68		110161-0-03	C-27	
///	A-13		100316-0-01	C-47		///	B-72		110319-0-00	B-47	
100241-0-01	A-23		100320-0-01	A-12		100591-0-01	A-7		110320-0-00	B-63	
100242-0-04	A-24		100320-0-02	C-50		100592-0-01	A-6		110340-0-01	C-5	
100248-0-01	B-29		100320-0-01	C-48		100597-0-00	B-32		110605-0-01	B-42	
100251-0-01	B-19		100322-0-01	C-46		100598-0-01	B-33		111274-0-01	B-75	
///	B-35		100324-0-03	C-53		100600-0-01	B-21		112190-0-01	B-10	
///	B-38		100326-0-03	C-45		100628-0-01	B-49		113280-0-01	C-7	
///	B-51		100327-0-01	C-43		100630-0-00	B-48		113353-0-01	C-44	
///	B-61		100328-0-01	C-42		100633-0-01	B-52		113547-0-01	C-18	
///	B-66		100330-0-03	C-55		100634-0-00	B-59		114931-0-01	A-28	
100252-0-01	B-20		100331-0-02	C-52		100637-0-00	B-73		115812-0-02	B-1	
100253-0-01	B-22		///	C-62		100638-0-00	B-67		116005-0-01	A-20	
100258-0-01	B-4		100332-0-01	C-58		101706-0-01	B-57		116231-0-01	A-47	
100259-0-01	B-3		100333-0-01	C-59		///	B-69		116951-0101	B-7	
100260-0-01	B-2		100335-0-01	B-81		1102575-0-01	A-44		116998-0-01	B-39	
///	B-6		100337-0-03	C-65		102627-0-01	C-34		117001-0-01	B-65	

D760-2




PARTS LIST FOR DBI-B760

B760-3


Ref.No.	Name of Parts	Q'ty	Parts-No.	Assembly No.	Ref No.	Name of Parts	Q'ty	Parts-No.	Assembly No.
A-1	Oil Pipe for B-14, B-21	2 pcs.	100235-0-00						
A-2	Oil Pipe for B-20	1 pc.	100235-0-00						
A-3	Oil Pipe for B-16	1 pc.	100235-0-00						
A-5	Set Screw for Rear Cover	1 pc.	100008-0-03						
A-6	Rear Cover	1 pc.	100592-0-01						
A-7	Oil Pipe & Supporter	1 pc.	100591-0-01						
A-8	Oil Pipe for B-32	1 pc.	100235-0-00						
A-9	Felt for A-10	1 pc.	100119-0-03						
A-10	Spool Pin	2 pcs.	100386-0-01						
A-11	Spool Pin Base	1 pc.	100385-0-01						
A-12	Set Screw for A-11	2 pcs.	100320-0-01						
A-13	Oil Pipe for B-37	2 pc.	100235-0-00						
A-14	Oil Pad for Hole of B-55	1 pc.	108520-0-01						
A-16	Face Plate	1 pc.	100391-0-01						
A-19	Set Screw for A-20	1 pc.	100393-0-01						
A-20	Face Plate Thread Guide F	1 pc.	116005-0-01	100390-0-01					
A-21	Face Plate Thread Guide E	1 pc.	100392-0-01						
A-22	Set Screw for A-21	1 pc.	100393-0-01						
A-17	Set Screw for A-16	1 pc.	100287-0-04						
A-18	Set Screw for A16	1 pc.	100395-0-01						
A-23	Cover Plate for B-4	1 pc.	100241-0-01						
A-24	Set Screw for A-24	1 pc.	100242-0-04						
A-25	Set Screw for A-26	1 pc.	103980-0-01						
A-26	Arm Thread Guide B	1 pc.	100389-0-01						
A-27	Set Screw for A-28	1 pc.	100388-0-04						
A-28	Thread Retainer A	1 pc.	114931-0-01						
A-29	Set Screw for A-31	1 pc.	103950-0-02						
A-30	Set Screw for A-34	1 pc.	100402-0-02						
A-31	Upper Thread Tension Bracket	1 pc.	100397-0-01						
A-32	Thread Releasing Pin	1 pc.	100400-0-00						
A-33	Thread Take Up Spring	1 pc.	100399-0-01	180195-0-01					
A-34	Tension Stud	1 pc.	100398-0-01						
A-35	Tension Disc	2 pcs.	108721-0-01						
A-36	Tension Disc Washer	1 pc.	100134-0-01						
A-37	Tension Spring	1 pc.	100401-0-01						
A-38	Thread Tension Control Nut	1 pc.	100136-0-01						
A-39	Slide Plate	1 pc.	100268-0-01						
A-40	Slide Plate Spring	1 pc.	100269-0-01	118289-0-01					
A-41	Slide Plate Spring Screw	2 pcs.	100035-0-01						
A-42	Needle Plate Screw	2 pc.	100032-0-01						
A-43	Needle Plate B-18	1 pc.	100268-0-01						
A-44	Armbud	1 pc.	102575-0-01						
A-45	Oil Cap for B-73	1 pc.	140890-0-01						
A-46	Model Plate	1 pc.	143256-0-01						
A-47	Model Plate Pin	2 pcs.	116231-0-01						

D760-4



Ref.No.	Name of Parts	Qty	Parts-No.	Assembly No.	Ref.No.	Name of Parts	Qty	Parts-No.	Assembly No.
B-1	Oil Felt for B-3	1 pce.	115812-0-02		B-42	Arm Pulley	1 pce.	10605-0-01	
B-2	Set Screw for B-3	1 "	100260-0-01		B-43	Cap Screw for B-30, B-42	1 "	104478-0-01	
B-3	Needle Bar Bushing Upper	1 "	100259-0-01	182060-0-01	B-44	Set Screw for B-42	2 pcs.	100016-0-03	
B-4	Needle Bar	1 "	100258-0-01		B-45	Oil Seal Right for B-30	1 pce.	103738-0-01	
B-5	Needle Bar Bushing Lower	1 "	109206-0-01		B-46	Oil Seal for B-55	2 pcs.	103796-0-01	
B-6	Set Screw for B-5	1 "	100260-0-01		B-47	Upper Gear Case	1 pce.	110319-0-00	
B-7	Needle Clamp	1 "	116951-0-01	180017-0-01	B-48	Grease Hole Cap B-47	1 "	100630-0-00	
B-8	Needle Clamp Screw	1 "	118521-0-01		B-49	Set Screw for B-47	1 "	100628-0-01	
B-9	Set Screw for B-10	1 "	100393-0-01		B-52	Oil Felt for B-53, B-59, B-67, B-73	4 pcs.	100633-0-01	
B-10	Needle Bar Thread Guide G	1 "	112190-0-01		B-53	Vertical Shaft Upper Bushing	1 pce.	103558-0-00	
B-11	Needle DBx1	1 "	100265-0-14		B-54	Set Screw for B-53	1 "	100016-0-03	
B-12	Clamp Screw for B-13	1 "	140004-0-01		B-55	Vertical Shaft	1 "	103557-0-01	
B-13	Needle Bar connecting Stud	1 "	102632-0-01	106121-0-01	B-58	Vertical Shaft Collar	1 "	100356-0-01	
B-14	Stud for Thread Take Up Support	1 "	104376-0-01		B-57	Set Screw for B-58	2 pcs.	101706-0-01	
B-15	Set Screw for B-14	1 "	100016-0-01		B-58	Set Screw for B-59	1 pce.	100016-0-03	
B-16	Thread Take Up	1 "	100271-0-01		B-59	Vertical Shaft Lower Bushing	1 "	100634-0-00	
B-20	Needle Bar Crank	1 "	100252-0-01		B-60	Vertical Shaft Lower Gear	1 "	117799-0-01	
B-21	Needle Bar Crank Rod	1 "	100600-0-01		B-61	Set Screw for B-60	1 "	100251-0-01	180145-0-01
B-22	Cap Screw for B-20	1 "	100253-0-01		B-65	Lower Shaft Gear	1 pce.	117001-0-01	
B-17	Thread Take Up Crank	1 "	142097-0-00		B-66	Set Screw for B-65	2 pcs.	100251-0-01	
B-18	Take Up Crank Position Screw	1 "	104461-0-01		B-62	Oil Seal for B-71	1 "	103797-0-01	
B-19	Set Screw for B-17	2 pcs.	100251-0-01		B-63	Lower Gear Case	1 "	110320-0-00	
B-23	Needle Bar Guide Slide Block	1 pce.	102630-0-01		B-64	Set Screw for B-63	1 "	100343-0-01	
B-24	Needle Bar Guide	1 "	102631-0-00		B-67	Lower Shaft Bushing Right	1 "	100638-0-00	
B-25	Set Screw for B-24	2 pcs.	100137-0-01		B-68	Set Screw for B-67	1 pce.	100539-0-02	
B-26	Set Screw for B-27	1 pce.	100016-0-03		B-69	Set Screw for B-70	2 pcs.	101706-0-01	
B-27	Upper Shaft Bearing Left	1 "	142102-0-00		B-70	Lower Shaft Collar	1 "	100356-0-01	
B-28	Wick 6x6 for B-27, B-32, B-41, B-53, B-59, B-67, B-73	7 pcs.	108805-0-01		B-71	Lower Shaft	1 "	100351-0-01	
B-29	Oil Felt for B-27, B-41	2 "	100248-0-01		B-72	Set Screw for B-73	1 "	100539-0-02	
B-30	Upper Shaft	1 pce.	142101-0-01		B-73	Lower Shaft Bushing Left	1 "	100637-0-00	
B-31	Set Screw for B-32	1 "	100016-0-03		B-75	Rotary Hook Assembly	1 "	111274-0-01	
B-32	Upper Shaft Bearing Intermediate	1 "	100597-0-00		B-76	Set Screw for B-77	1 "	100368-0-02	
B-33	Oil Felt for B-32	1 "	100598-0-01		B-77	Hobbin Case Holder position Bracket	1 "	100367-0-01	
B-34	Upper Shaft Collar	1 "	104274-0-00		B-78	Hobbin	1 "	117132-0-01	
B-35	Set Screw for B-34	2 pcs.	100251-0-01		B-79	Hobbin Case	1 pce.	100309-0-01	
B-36	Set Screw for B-37	2 "	100013-0-03		B-80	Set Screw for B-81	2 pcs.	107428-0-01	
B-37	Feed & Feed Lifting Eccentric	1 pce.	100307-0-00		B-81	Crank Rod	1 pce.	100335-0-01	
B-87	Steeve for B-37	1 "	106424-0-04	180192-0-01	B-82	Taper Screw B-81	1 "	100310-0-01	
B-38	Set Screw for B-39	2 pcs.	100251-0-01		B-83	Nut for B-82	1 "	104689-0-01	
B-39	Upper Shaft Gear	1 pce.	116998-0-01	180144-0-01	B-84	Taper Hinge Screw for B-86	1 "	100310-0-01	
B-50	Vertical Shaft Gear	1 "	117797-0-01		B-85	Nut for B-84	1 "	104689-0-01	
B-51	Set Screw for B-50	2 pcs.	100251-0-01		B-86	Feed Forked Connecting	1 "	100309-0-01	
B-40	Set Screw for B-41	1 "	100062-0-04		B-88	Pat for B-87	1 "	106442-0-01	
B-41	Upper Shaft Bearing Right	1 "	103555-0-00		B-89	Felt Wire for B-87	1 "	106440-0-00	

B760-6



Ref.No.	Name of Parts	Qty	Parts-No.	Assembly No.	Ref.No.	Name of Parts	Qty	Parts-No.	Assembly No.
C-1	Pressor Foot Control Screw	1 pco.	100279-0-01		U-46	Length Control Screw	1 pco.	100322-0 01	
C-2	Pressor Spring Washer	1 "	141099-0-01		C-47	Direction Control	1 "	100316-0-01	
C-3	Pressor Spring	1 "	117880-0-01		C-48	Stud Screw for C-47	1 "	100321-0-01	
C-4	Pressor Bar	1 "	103013-0-01		C-50	Clamp Screw for C-47	1 "	100320-0-02	
C-5	Pressor Bar Bushing	1 "	110340-0-01		C-51	Nut for C-52	2 pco.	100075-0-03	
C-6	Pressor Foot Set Screw	1 "	100287-0-04		C-52	Center Screw for C-55	2 "	100331-0-02	
C-7	Pressor Foot	1 "	113280-0-01		C-53	Feed Rock Shaft Arm	1 pco.	100324-0 03	
C-8	Stud Screw for C-9	1 "	109801-0-01		C-54	Clamp Screw for C-53	1 "	100086-0-03	
C-9	Pressor Lifter	1 "	100291-0-01		C-55	Feed Rock Shaft	1 "	100330-0-03	
C-10	Set Screw for C-8	1 "	100013-0-02		C-56	Set Screer for C-57	2 pco.	100080-0-03	
C-11	Pressor Bar Guide Bracket	1 "	100288-0-01		C-57	Feed dog	1 pco.	100330-0-01	100-334-00
C-12	Set Screw for C-11	1 "	100013-0-03		C-58	Feed Bar	1 "	100332-0-01	
C-13	Set Screw for C-14	1 "	100080-0-03		C-59	Center Screw for C-58	2 pco.	100333-0-01	
C-14	Pressor Bar Bracket Thread Guide for C-11	1 "	117178-0-01		C-60	Nut for C-59	2 "	100078-0-03	
C-15	Stud Screw for C-20	1 "	100294-0-01		C-61	Nut for C-62	2 "	100095-0-03	
C-16	Pressor Lifter Bracket	1 "	100290-0-01		C-62	Center Screw for C-65	2 "	100331-0-02	
C-17	Taper pin for C-18	1 "	100404-0-00		C-63	Feed Lifting Arm Assembly	1 pco.	100338-0-01	
C-18	Tension Release Crank	1 "	113547-0-01		C-64	Clamp Screw for C-63	1 "	100096-0-03	
C-19	Tension Release Crank Spring	1 "	100405-0-01		C-65	Feed Lifting Lock Shaft	1 "	100317-0-03	
C-20	Pressor Bar Lifting Connector	1 "	100293-0-01		C-67	Direction Control Spring	1 "	117847-0-01	
C-21	Knee Lifter Pin	1 "	100297-0-01						
C-22	Set Screw for C-21	1 "	100013-0-03						
C-23	Knee Lifter Lever	1 "	100295-0-01						
C-24	Hinge Screw for C-23	1 "	102921-0-02						
C-25	Stud Screw for C-26	1 "	100299-0-01						
C-26	Knee Lifter Joint	1 "	100298-0-01						
C-27	Nut for C-28	1 "	110161-0-03						
C-28	Knee Lifter Connecting Rod	1 pco.	100300-0-01						
C-29	Hinge Pin for C-30	1 "	118550-0-00						
C-30	Knee Lifter Crank beneath Rod	1 "	117924-0-01						
C-31	Spring for C-30	1 "	100304-0-01						
C-32	Set Screw for C-33	2 pco.	100306-0-03						
C-33	Bracket for C-30	1 pco.	100305-0-01						
C-34	Set Screw for C-41	1 "	102627-0-01						
C-35	Feed Regulator	1 "	100313-0-01						
C-37	Stud Screw for Feed Regulator	1 "	141098-0-01						
C-38	Taper Hinge Screw	1 "	100310-0-01						
C-39	Feed Regulator Link	1 "	100311-0-00						
C-40	Nut for C-38	1 "	104689-0-01						
C-41	Taper Hinge for C-35	1 "	100312-0-01						
C-42	Spring for C-43	1 "	100328-0-01						
C-43	Notch Pin for C-44	1 "	100327-0-01						
C-44	Length Control	1 "	113353-0-01						
C-45	Set Screw for C-44	1 "	100328-0-03						