

**SINGER**  
**112W131**


Form 2731w  
(741)  
Printed in U. S. A.

# SINGER

112w131




THE SINGER MANUFACTURING COMPANY






Copyright, U. S. A., 1939, 1940 and 1941  
by The Singer Manufacturing Co.  
All Rights Reserved for all Countries

13067 - 1/2




16257 - 1/6

259143




16260 - 1/2

224140




200700

16261 - 1/2




16615 - 1/2




16643 - 3/8

228368




16644 - 1/3






17763 - 3/8

236831




17764 - 3/8








17765




17766








17771 - 2/3




17772 - 1/3



17773 - 3/4


236923-46  
236924-50 1/2 1/32 1/16 1 9/32 5/8




203376

691F


236925-46




236926-46



236929-46  
236930-50




236907




200106E


236909



236908




236910




17774 - 3/4


236922-50  
1 3/32 7/16 1 5/32 1/2




236906



236918-46  
1 7/32 9/16  
236916-46  
1 9/32 5/8 2 1/2 1 1/16



236915-46  
2 3/32 3/4  
236917-46  
2 5/32 1 3/16 2 7/32 7/8 2 9/32 1 5/16 3 1/32 1



236914-46  
1 3/32 7/16 1 5/32 1/2 1 7/32 9/16

